

HR-PS II

1MAX-HRPS2_HR-PSII_0 290910 IV



Index No.	Parts No.	Parts Name	Index No.	Parts No.	Parts Name
1	HR 10273	Cap Seal	31	KK 14003	Torsion Spring 4003
2	AA 21005	+, Screw 4 × 10	32	FF 41260	Pin 1260
3	HR 10278	Magazine Unit	33	HR 10271	Ring
4	AA 21002	+, Screw 4 × 8	34	HR 10205	Poly Guide Unit
5	HR 10234	Cutter Holder B	35	HR 10227	Base Rubber
6	HR 10609	Chincher Cover	36	HR 10256	Bearing Unit A
7	HR 10059	Cutter	37	FF 30270	Pin 0270
8	HR 10231	Cutter Holder A	38	FF 30252	Pin 252
9	HR 10277	Screw	39	FF 30269	Pin 0269
10	HR 10228	Clincher Holder Unit	40	HR 10208	Link-A
11	HR 10232	Ckincher	41	HR 12011	Link-C
12	CC 41003	Hex. Nut 1-5	42	HR 10608	Link Coller
13	EE 11113	Spring Washer 2-5	43	KK 34023	Torsion Coil Spring 4023
14	HR 10265	Roller Plate Guide	44	HR 10605	Main Shaft Unit
15	HR 10611	cover-L	45	KK 34024	Torsion Coil Spring 4024
16	HR 10242	Seal B	46	HR 10257	Bearing Unit B
17	CC 41002	Hex. Nut 1-4	47	AA 21011	+, Screw 5 × 12
18	HR 10204	Roller	48	HR 10215	Lower Frame
19	HR 10198	Driver Unit	49	BB 71002	Hex. Bolt 6 × 18
20	HR 10241	Seal A	50	HR 10224	Base Unit
21	HR 10603	Roller Plate Unit	51	EE 11114	Spring Washer 2-6
22	JJ 10001	E-Ring 8	52	CC 41004	Hex. Nut 1-6
23	HR 10601	Upper Frame Unit	53	HR 10036	Grip
24	AA 21010	+, Screw 5 × 6	54	HR 10220	Lever Unit
25	AA 22001	+, Screw 4 × 10	55	HR 10610	Cover-R
26	BB 40101	Hex. Nut 4 × 12	56	HR 10223	Shaft Pin
27	HR 10290	Slide Driver Guide Unit	57	HR 10614	Link Stopper
28	HR 10268	Sequence Plate Unit	58	HR 10236	Look Nut
29	JJ 10002	E-Ring 5	59	HR 10235	Adjustable Screw
30	HR 10270	Guide Stopper			

