


MODEL MS6564

SPOTNAILS®

DIVISION OF PEACE INDUSTRIES, LTD.

1100 Hicks Rd
Rolling Meadows, IL 60008
Phone : 847-259-1620



SPOTNAILS MODEL MS6564

Ref No.	Part No.	Description		Ref No.	Part No.	Description	
01	P-24370	Screw		38	P-07262	Pin	
02	P-96118	Bushing	◆	39	P-64332	Valve Housing O-Ring	
03	P-70047	Exhaust Deflector		40	P-22144	Trigger Valve Cap	
04	P-64377	O-Ring	◆	41	P-64333	O-Ring	
05	P-24314	Cap Screw	◆	42	P-64334	O-Ring	
06	P-32169	Flat Washer	◆	43	P-64335	O-Ring	
07	P-60181	Cap		44	P-22145	Pilot Valve	
◆	08	P-62080	Gasket	◆	45	P-64336	O-Ring
	09	P-03076	Spacer		46	P-18227	Spring
	10	P-15204	Exhaust Seal	◆	47	P-64383	Plunger O-Rings
	11	P-18442	Poppet Spring		48	AS-22037	Plunger Assembly
◆	12	P-64399	Poppet O-Ring	◆	50	P-64328	O-Ring
	13	P-63043	Poppet		51	AS-21008	Trigger Assembly
◆	14	P-64426	Poppet O-Ring		52	P-07327	Trigger Pin
◆	15	P-64312	Cylinder Seal O-Ring	◆	53	P-64240	O-Ring
◆	16	P-64427	Piston O-Ring		54	P-13082	Bracket
	17	AS-06072	Piston & Driver Assembly		55	P-24370	Screw
	18	P-06252	Driver Blade		56	P-24353	Screw
	19	P-03082	Guide Spacer		57	P-12436	Magazine Cover (A)
◆	20	P-64228	Cylinder O-Ring		58	P-18131	Spring Clip
	21	P-05108	Cylinder		59	P-18298	Negator Spring
◆	22	P-64429	O-Ring		60	P-12476	Magazine
	23	P-15215	Bumper		61	P-24383	Screw
	24	P-15218	Return Seal		62	P-32180	E-Ring
	25	P-01272	Body		63	P-07346	Cover Pin
	26	P-64312	O-Ring		64	P-18228	Spring
	27	P-60156	End Cap		65	P-32170	Washer
	28	P-64430	O-Ring		66	P-26142	Nut
	29	P-60182	Bottom Plate		67	P-12437	Magazine Cover (B)
	30	P-24453	Screw		68	P-03083	Bushing
	31	P-10307	Removable Front Plate		69	P-09210	Pusher
	32	P-24358	Screw		70	P-97454	Filter (Optional)
	33	P-08492	Wear Plate		71	AS-04038	Latch Assembly
	34	P-07257	Safety Yoke Pin		72	P-07354	Pin
	35	P-53165	Safety Guide		73	P-07355	Pin
	36	P-18328	Spring		74	P-10306	Stationary Front Plate
	37	AS-53062	Safety Assembly				

◆ Parts Included In AS-97300 O-Ring And Seal Kit