


# MODEL MS7564

# SPOTNAILS®

DIVISION OF PEACE INDUSTRIES, LTD.

1100 Hicks Rd  
Rolling Meadows, IL 60008  
Phone : 847-259-1620



7/25/2005

## SPOTNAILS MODEL MS7564

Ref No.	Part No.	Description
01	P-24370	Screw
02	P-96118	Bushing
03	P-70047	Exhaust Deflector
04	P-64377	O-Ring
05	P-24314	Cap Screw
06	P-32169	Flat Washer
07	P-60181	Cap
◆	08	P-62080 Gasket
	09	P-03076 Spacer
	10	P-15204 Exhaust Seal
	11	P-18442 Poppet Spring
◆	12	P-64399 Poppet O-Ring
	13	P-63043 Poppet
◆	14	P-64426 Poppet O-Ring
◆	15	P-64312 Cylinder Seal O-Ring
◆	16	P-64427 Piston O-Ring
	17	AS-06060 Piston & Driver Assembly
	18	P-06241 Driver Blade
	19	P-03082 Guide Spacer
◆	20	P-64228 Cylinder O-Ring
	21	P-05108 Cylinder
◆	22	P-64429 O-Ring
	23	P-15215 Bumper
	24	P-15218 Return Seal
	25	P-01272 Body
	26	P-64312 O-Ring
	27	P-60156 End Cap
	28	P-64430 O-Ring
	29	P-60182 Bottom Plate
	30	P-24453 Screw
	31	P-10308 Stationary Front Plate
	32	P-24358 Screw
	33	P-08483 Wear Plate
	34	P-07257 Safety Yoke Pin
	35	P-53165 Safety Guide
	36	P-18328 Spring
	37	AS-53062 Safety Assembly

Ref No.	Part No.	Description
38	P-07262	Pin
39	P-64332	Valve Housing O-Ring
40	P-22144	Trigger Valve Cap
41	P-64333	O-Ring
42	P-64334	O-Ring
43	P-64335	O-Ring
44	P-22145	Pilot Valve
45	P-64336	O-Ring
46	P-18227	Spring
47	P-64383	Plunger O-Rings
48	AS-22037	Plunger Assembly
49	P-64328	O-Ring
50	P-64328	O-Ring
51	AS-21008	Trigger Assembly
52	P-07327	Trigger Pin
◆	53	P-64240 O-Ring
	54	P-13082 Bracket
	55	P-24370 Screw
	56	P-24353 Screw
	57	P-12436 Magazine Cover (A)
	58	P-18131 Spring Clip
	59	P-18298 Negator Spring
	60	P-12444 Magazine
	61	P-24383 Screw
	62	P-32180 E-Ring
	63	P-07346 Cover Pin
	64	P-18228 Spring
	65	P-32170 Washer
	66	P-26142 Nut
	67	P-12437 Magazine Cover (B)
	68	P-03083 Bushing
	69	P-09183 Pusher
	70	P-97454 Filter (Optional)
	71	AS-04038 Latch Assembly
	72	P-07354 Pin
	73	P-07355 Pin
	74	P-10309 Removable Front Plate

◆ Parts Included In AS-97300 O-Ring And Seal Kit