

MODEL MT9764


SPOTNAILS®

DIVISION OF PEACE INDUSTRIES, LTD.

1100 Hicks Rd

Rolling Meadows, IL 60008

Phone : 847-259-1620



SPOTNAILS MODEL MT9764

Ref No.	Part No.	Description	
01	P-24370	Screw	
02	P-96118	Bushing	
03	P-70047	Exhaust Deflector	
04	P-64377	O-Ring	
05	P-24314	Cap Screw	
06	P-32169	Flat Washer	
07	P-60181	Cap	
◆	08	P-62080	Gasket
	09	P-03076	Spacer
	10	P-15204	Exhaust Seal
	11	P-18442	Poppet Spring
◆	12	P-64399	Poppet O-Ring
	13	P-63043	Poppet
◆	14	P-64426	Poppet O-Ring
◆	15	P-64312	Cylinder Seal O-Ring
◆	16	P-64427	Piston O-Ring
	17	AS-06074	Piston & Driver Assembly
	18	P-06254	Driver Blade
	19	P-03082	Guide Spacer
◆	20	P-64401	Cylinder O-Ring
	21	P-05108	Cylinder
◆	22	P-64429	O-Ring
	23	P-15215	Bumper
	24	P-15200	Return Seal
	25	P-01272	Body
	26	P-64312	O-Ring
	27	P-60156	End Cap
◆	28	P-64430	O-Ring
	29	P-60182	Bottom Plate
	30	P-24453	Screw
	31	P-10310	Stationary Front Plate
	32	P-24385	Screw
	33	P-12481	Guide Nail Cover
	34	P-24317	Screw
	35	P-08493	Wear Plate

Ref No.	Part No.	Description	
36	P-10260	Removable Front Plate	
37	P-52036	Safety Yoke Guide	
38	P-24306	Screw	
39	P-24364	Screw	
40	P-53169	Short Guide Assembly	
41	P-53165	Safety Guide	
42	P-18328	Spring	
43	AS-53069	Safety Assembly	
44	P-07262	Pin	
◆	45	P-64332	Valve Housing O-Ring
	46	P-22144	Trigger Valve Cap
◆	47	P-64333	O-Ring
◆	48	P-64334	O-Ring
◆	49	P-64335	O-Ring
	50	P-22145	Pilot Valve
◆	51	P-64336	O-Ring
	52	P-18227	Spring
◆	53	P-64383	Plunger O-Rings
	54	AS-22037	Plunger Assembly
◆	55	P-64328	O-Ring
	56	AS-21008	Trigger Assembly
◆	57	P-64240	O-Ring
	58	P-07327	Trigger Pin
	59	P-26143	Nut
	60	P-24383	Screw
	61	P-13093	Bracket
	62	P-26126	Nut
	63	P-09165	Pusher
	64	P-18234	Negator Spring
	65	P-12370	Magazine (Left)
	66	P-12369	Magazine (Right)
	67	P-03056	Spacer
	68	P-24319	Screw
	69	P-97454	Filter (Optional)

◆ Parts Included In AS-97285 O-Ring And Seal Kit