




MODEL: AS-4090




PARTSLIST AS-4090

* WHEN ORDERING SPARE PARTS, PLEASE STATE ITEM NO. "PART NO. AND DESCRIPTION.

2007.01.19

ITEM	PART NO	DESCRIPTION	ITEM	PART NO	DESCRIPTION	ITEM	PART NO	DESCRIPTION
1	HS0512B	UN.HD.BOLT	34	12103401	TRIGGER VALVE HEAD	78	HS0510B	HEX.SOC.HD.BOLT
2	20900201	EXHAUST COVER	35	12103501	TRIGGER VALVE STEM	79	E90407902	PLATE, NOSE
3	10200501	SEAL	37	OR1119R	O-RING**	80	F32978101	FOOT
4	HS0520BW	HEX.SOC.HD.BOLTSR	38	12103801	TRIGGER VALVE GUIDE	81	C32977801	WASHER BUSHING(L)
5	SS0406S	SET SCREW	39	12104001	TRIGGER	84	JHS0412BW	HEX.SOC.HD.BOLT
6	20900601	CAP	43	FH0416B	FLAT.HD.BOLT	85	JHS0408B	HEX.SOC.HD.BOLT
7	20900701	PISTON STOPPER**	46	25604601	NOSE	86	F90408601	GUIDE, FRONT
8	OR1224R	O-RING	47	11304701	SET PLATE	87	C90408702	WASHER BUSHING
9	20900901	COLLAR	48	12504801	SET PLATE	88	JMS0540B	HEX.SOC.HD.BOLT
10	OR4025R	O-RING**	49A	25604901A	STAPLE GUIDE UNIT	89	LN0500N	LOCK NUT(M5)
11	20901101	SPRING**	50	12505004	MAGAZINE			
12	20901201	PISTON HEAD VALVE	51	12505101	PUSHER			
13	20901301	STOPPER	52	11205201	SLIDE BLOCK			
14	OR3235	O-RING**	53	11305301	SPRING**			
15	OR2835R	O-RING**	54	11305401	ROD			
16A	22801602A	DRIVER ASSEMBLY**	56	11305601	SET BLOCK			
17	20901701	CYLINDER	57	HS0408B	HEX.SOC.HD.BOLT			
18	OR3825R	O-RING**	58	12505802	END CORE			
19	20901901	BUMPER**	59	13908101	STOPPER			
20	20902001	GASKET**	60	11106002	SPRING**			
21	OR1919H	O-RING**	62	13908401	STEPPED PIN			
22	22902201	BODY	63	HS0410B	HEX.SOC.HD.BOLT			
23	HS0516B	HEX.SOC.HD.BOLT	64	10206201	SET PLATE			
24	12106401	AIR PLUG	65	11009101	TOR.SPRING			
25	12502501	JOINT GUIDE	66	11002801	TRIGGER			
27	ER0200H	E RING	67	12103901	SPRING**			
32	12103202	STEPPED PIN	68	12506801	SET FLATE			
33	12103301	SEAL	69	12706901	BRACKET			

MODEL: AS-3290




PART LIST (AS-3290)

** WHEN ORDERING SPARE PARTS, PLEASE STATE ITEM NO., PART NO., AND DESCRIPTION.

ITEM	PART NO.	DESCRIPTION	QTY	REMARK	ITEM	PART NO.	DESCRIPTION	QTY	REMARK
1	HS0530BW	HEX.SOC.HD.BOLT + SW	4	M5X30L	45A	15104501A	TRIGGER ASSEMBLY	1	
3	I3900305	CAP	1		46-1	11204603	NOSE	1	
4	I2100401	SEAL	1		47	12204701	SET PLATE	1	
5	I2100501	SPRING	1		48	12104501	SET PLATE	1	
6	OR1425R	O-RING	1		49A-1	12204902A	STAPLE GUIDE UNIT	1	
7	I1100701	CAP SEAL	1		50	12205001	MAGAZINE	1	
8A	I3900801A	HEAD VALVE ASM.	1		51	11205101	PUSHER	1	
11	OR3224R	O-RING	1		52	11205201	SLIDE BLOCK	1	
13-1	OR2635R	O-RING	1		53	11305301	SPRING	1	
13-2	I3901305	PISTON RING	1		54	11305401	ROD	1	
14A	I9301402A	DRIVER ASSEMBLY (1-PC)	1		55	11305501	SHAFT	1	
18	OR4630R	O-RING	1		56	11305601	SET BLOCK	1	
19-1	I9301901	CYLINDER	1		58A	12205801A	END CORE ASM.	1	
19-2	I9301901G	CYLINDER	1		59	US0510B	UM.HD.BOLT	1	M5X10L
19-3	I3901903	COLLAR	1		63	HS0410B	HEX.SOC.HD.BOLT	2	M4X10L
20	I3902001	BUMPER	1		64	I2106401	AIR PLUG	1	
21	OR3520R	O-RING	1		65	LN0500N	LOCK NUT	1	
22	OR3635R	O-RING	1		66	11106601	COVER	1	
23	I1102307	BODY	1		67	HS0516B	HEX.SOC.HD.BOLT	1	M5X16L
24	OR1919H	O-RING	1		68	OR4030R	O-RING	1	
25	I2102501	JOINT GUIDE	1		69	I1306902	BRACKET	1	
26	I1002601	SPRING	1		71	US0506B	UM.HD.BOLT	1	
27	I1002702	GUIDE SAFETY LEVER	1		72	FW0512W	FLAT WASHER	1	
32	I2103202	STEPPED PIN	1		73	I2103301	SEAL	1	
33	OR0319R	O-RING	1		74	I3907403	EXHAUST COVER	1	
34	I1003401	TRIGGER VALVE HEAD	1		75	RP3010S	ROLLED PIN	1	
35	I1003503	TRIGGER VALVE STEM	1		76A	E32977601	PLATE, NOSE	1	A PLATE
36	OR2515H	O-RING	1		76B	E32977602	PLATE, NOSE	1	B PLATE
37	OR1119R	O-RING	1		77	F32977701	GUIDE, FRONT	1	
38	I1003803	TRIGGER VALVE GUIDE	1		78	H32977801	WASHER BUSHING	6	Ø11X7.8
39	I1006901	SPRING	1		79	JHS0416BW	HEX.SOC.HD.BOLT + SW	10	M4X16L
41	HS0406B	HEX.SOC.HD.BOLT	2	M4X06L	80	H32978001	WASHER BUSHING	4	Ø11X9.6
43	FH0412B	FLAT.HD.BOLT	2	M4X12L	81	F32978101	FOOT	4	
44	HS0520BW	HEX.SOC.HD.BOLT + SW	2	M5X20L	82	D32978201	SAFETY UPPER CONTACT	1	

MODEL: AS-3297



AS-3297 Part List

Date : 93/11/19

Item	Part No	Description	Qty	Remark	Item	Part No	Description	Qty	Remark
1	HS0530BW	HEX.SOC.HD.BOLT	4	M5X30L	44	HS0520BW	HEX.SOC.HD.BOLT	2	M5X20L
3	13900305	CAP	1		46	20804601	NOSE	1	
4	12100401	SEAL	1		47	12204701	SET PLANT	1	
5	12100501	SPRING	1		48	12104501	SET PLANT	1	
6	OR1425R	O-RING	1		49A	20804901A	STAPLE GUIDE UNIT	1	
7	11100701	CAP SEAL	1		50	20805001	MAGAZINE	1	
8A	13900801A	PISTON HEAD VALVE ASM	1		51	20805101	PUSH	1	
11	OR3224R	O-RING	1		52	20805201	SLIDE BLOCK	1	
13	OR2635R	O-RING	1		53	11305301	SPRING	1	
13A	13901301A	OIL-LESS PISTON RING ASM	1		54	11305401	ROD	1	
14A	20801401A	DRIVER ASSEMBLY	1		55	11305501	SHAFT	1	
18	OR4630R	O-RING	1		56	11305601	SET BLOCK	1	
19-1	19301901	CYLINDER	1		58A	12205801A	END CORE ASSEMBLY	1	
19-2	19301901G	CYLINDER	1		59	US0510B	UM.HD.BOLT	1	M5X10L
19-3	13901903	COLLAR	1		63	HS0410B	HEX.SOC.HD.BOLT	1	M4X10L
20	13902001	BUMPER	1		64	HS0516B	HEX.SOC.HD.BOLT	1	M5X16L
21	OR3520R	O-RING	1		65	LN0500N	LOCK NUT	1	
22	OR3635R	O-RING	1		66	11106601	COVER	1	
23	11102307	BODY	1		67	12106401	AIR PLUG	1	
24	OR1919H	O-RING	1		68	OR4030R	O-RING	1	
25	12102501	JOINT GUIDE	1		69	11306902	BRACKET	1	
26	11002601	SPRING	1		71	US0506B	UM.HD.BOLT	1	
27	11002702	GUIDE SAFETY LEVER	1		72	FW0512W	FLAT WASHER	1	
32	12103202	STEPPED PIN	1		73	12103301	SEAL	1	
33	OR0319R	O-RING	1		74	13907403	EXHAUST COVER	1	
34	11003401	TRIGGER VALVE HEAD	1		75	RP3010S	ROLLED PIN	1	
35	11003503	TRIGGER VALVE STEM	1		76A	E32977601	PLATE, NOSE	1	A
36	OR2515H	O-RING	1		76B	E32977602	PLATE, NOSE	1	B
37	OR1119R	O-RING	1		77A	F32977701	GUIDE, FRONT	2	
38	11003803	TRIGGER VALVE GUIDE	1		78A	C32977801	WSHER BUSHING	8	φ 11x7.8
39	11006901	SPRING	1		79A	JHS0416BW	HEX.SOC.HD.BOLT	12	M4X16L
40A	15104501A	TRIGGER ASSEMBLY	1		80A	C32978001	WSHER BUSHING	4	φ 11x9.6
41	JFS0406B	HEX.SOC.HD.BOLT	2	M4X6L	81A	F32978101	FOOT	4	
43	JFS0412B	HEX.SOC.HD.BOLT	2	M4X12L	82A	D32978201	SAFETY UPPER CONTACT	1	