


MODEL:TYI-9040H



PARTS LIST(TYI-9040H)

*When ordering spare parts, please state item no, port no. and description.

ITEM	PART NO	DESCRIPTION	ITEM	PART NO	DESCRIPTION	ITEM	PART NO	DESCRIPTION
1	US0506B	UM.HD.BOLT	31	12102601	SPRING GUIDE	65	12506801	SET PLATE
2	FW0512W	FLAT.WASHER	32	13002701	GUIDE SAFETY LEVER	66	13908101	STOPPER
3	12103301	SEAL	33	12102801	SPRING	67	11106001	SPRING
4	13907403	EXHAUST COVER	34	14603401	SAFETY LEVER	68	12505802	END CORE
5	HS0520B	HEX.SOC.HD.BOLT	36	OR0319R	O RING	69	13908401	STEPPED PIN
6	17300604	CAP	37	11003401	TRIGGER VALVE HEAD	70	15107001	GASKET
7	SW0500W	SPRING WASHER	38	11006901	SPRING	71	15107101	REAR COVER
8	13600801	SPACER	39	17303501	TRIGGER VALVE STEM	72	12106401	AIR PLUG
9	13600901	PISTON STOPPER	40	OR2515H	O RING	73	HS0520B	HEX.SOC.HD.BOLT
10	13601001	SPRING	41	OR1119R	O RING	73-1	FW0513W	FLAT WASHER
11	OR3420R	O RING	42	11003803	TRIGGER VALVE GUIDE	74	HS0516B	HEX.SOC.HD.BOLT
12	13601201	PISTON HEAD VALVE	45A	15104501A	TRIGGER ASSEMBLY	75	SW0500W	SPRING WASHER
13	OR4720R	O RING	48	HS0406B	HEX.SOC.HD.BOLT	76	HS0410B	HEX.SOC.HD.BOLT
14	13601401	SEAL	49	11604201	NOSE COVER	77	14607701	BRACKET
15A	13601501A	OIL-LESS PISTON RING ASM.	50	HS0416B	HEX.SOC.HD.BOLT	78	LN0500N	LOCK NUT
16A-1	14001601A	PISTON ASSEMBLY	50-1	SW0400W	SPRING WASHER	78-1	FW0513W	FLAT WASHER
16A-2	14001602A	PISTON ASSEMBLY	51	HS0520B	HEX.SOC.HD.BOLT	80	ER0200H	E RING
18	17301801	COLLAR	52	SW0500W	SPRING WASHER			
19	OR6026R	O RING	53	12504601	NOSE			
20	OR4325R	O RING	54	11304701	SET PLATE			
21	17302101G	CYLINDER	55	12504801	SET PLATE			
21-1	OR4435R	O RING	56A	12504901A	STAPLE GUIDE UNIT			
22	17302201	BUMPER	57	12505004	MAGAZINE			
23	14002301	WASHER	58	12505101	PUSHER			
24	17302401	GASKET	59	11205201	SLIDE BLOCK			
25	12502501	JOINT GUIDE	60	11305301	SPRING			
26	OR1919H	O RING	61	11305401	ROD			
27	17302703	BODY	63	11305601.	SET BLOCK			
28	12103202	STEPPED PIN	64	HS0408B	HEX.SOC.HD.BOLT			