


MODEL: TYI-0830MT



P1141

PARTS LIST (TYI-0830MT)

*WHEN ORDERING SPARE PARTS, PLEASE STATE ITEM No., PART No. AND DESCRIPTION.

ITEM	PART NO	DESCRIPTION	ITEM	PART NO	DESCRIPTION	ITEM	PART NO	DESCRIPTION
1	HS0520BW	HEX. SOC. HD. BOLT+SW	42	US0520B	UM. HD. BOLT			
3	11100302	CAP	43	SW0500W	SPRING WASHER			
4	12100401	SEAL**	44A	11504401A	DRIVER GUIDE COVER ASM			
5	12100501	SPRING**	44	11504401	DRIVER GUIDE COVER			
6	OR1425R	O RING**	45	12104501	SET PLATE			
7	11100701	CAP SEAL**	46	HS0412B	HEX. SOC. HD. BOLT			
8A	12100801A	HEAD VALVE ASM.	47	11504701	DRIVER GUIDE			
11	OR3224R	O RING**	48	11504801	MAGAZINE COVER			
13-1	OR1830R	O RING**	49	SS0412S	SET SCREW			
13-2	11501303	PISTON RING	50	11505001	MAGAZINE			
14A-1	11501401A	DRIVER ASSEMBLY**	51	HS0406B	HEX. SOC. HD. BOLT			
14A-2	11501402A	DRIVER ASSEMBLY**	52	11105202	END CORE			
18	OR4630R	O RING**	53	11505301	PUSHER			
19-1	11401901	CYLINDER	54	12105401	SPRING**			
19-2	11401901G	CYLINDER	55	12105501	NAIL GUIDE LINER			
19-3	11101903	COLLAR	56	13908201	SET PLATE			
20	11502001	BUMPER**	57	HS0507B	HEX. SOC. HD. BOLT			
21	OR3018R	O RING**	58	HS0408BW	HEX. SOC. HD. BOLT+SW			
23	11102307	BODY	60	11106001	SPRING**			
24	OR1919H	O RING**	61	11106102	BRACKET			
25	12102501	JOINT GUIDE	62	13908401	STEPPED PIN			
26	11002601	SPRING	63	13908101	STOPPER			
27	11002702	GUIDE SAFETY LEVER	64	HS0516B	HEX. SOC. HD. BOLT			
31	11003101	SAFETY LEVER	65	LN0500N	LOCK NUT			
32	12103202	STEPPED PIN	66	11106601	COVER			
33	OR0319R	O RING**	67	12106401	AIR PLUG			
34	11003401	TRIGGER VALVE HEAD	68	OR4030R	O RING**			
35	11003503	TRIGGER VALVE STEM	70	HS0408B	HEX. SOC. HD. BOLT			
36	OR2515H	O RING**	71	US0506B	UM. HD. BOLT			
37	OR1119R	O RING**	72	FW0512W	FLAT WASHER			
38	11003803	TRIGGER VALVE GUIDE	73	12103301	SEAL			
39	11006901	SPRING	74	13907403	EXHAUST COVER			
40A	15104501A	TRIGGER ASSEMBLY	76	RP3018S	ROLLED PIN			
41A	13104101A	LATCH**	77	ER0200H	E RING			

NO: P1141