


MODEL: TYI-1650L



P13310 08/23/04

PARTS LIST (TYI-1650L) *WHEN ORDERING SPARE PARTS, PLEASE STATE ITEM No, PART No. AND DESCRIPTION.

ITEM	PART NO	DESCRIPTION	ITEM	PART NO	DESCRIPTION	ITEM	PART NO	DESCRIPTION
1	HS0530BW	HEX. SOC. HD. BOLT+SW	39	11006901	SPRING	75	HS0406B	HEX. SOC. HD. BOLT
3	13900305	CAP	40A	15104501A	TRIGGER ASSEMBLY	76	13908201	SET PLATE
4	12100401	SEAL**	41	HS0508B	HEX. SOC. HD. BOLT	77	ER0200H	E RING
5	12100501	SPRING**	42	HS0520BW	HEX. SOC. HD. BOLT+SW			
6	OR1425R	O RING	44	13104402	DRIVER GUIDE COVER			
7	11100701	CAP SEAL**	45	12104501	SET PLATE			
8A	13900801A	HEAD VALVE ASM.	46	HS0412B	HEX. SOC. HD. BOLT			
11	OR3224R	O RING**	47	13704702	DRIVER GUIDE			
13-1	OR2635R	O RING**	48	13704802	MAGAZINE COVER			
13-2	13901305	PISTON RING	49	SS0412S	SET SCREW			
14A-1	13301401A	DRIVER ASSEMBLY**	50	13305002	MAGAZINE			
14A-2	13301402A	DRIVER ASSEMBLY**	51	HS0408BW	HEX. SOC. HD. BOLT+SW			
18	OR4630R	O RING**	52	13906103	BRACKET			
19-1	13301901	CYLINDER	53	13705301	PUSHER			
19-2	13301901G	CYLINDER	54	12105401	SRPING**			
19-3	13901903	COLLAR	55	12105501	NAIL GUIDE LINER			
20	13902001	BUMPER**	57	US0506B	UM. HD. BOLT			
21	OR3520R	O RING**	58	13908401	STEPPED PIN			
22	OR3635R	O RING**	59	13908101	STOPPER			
23	13902301	BODY	60	11106001	SPRING**			
24	OR1919H	O RING**	61	13905202	END CORE			
25	13702501	JOINT GUIDE	62	HS0408B	HEX. SOC. HD. BOLT			
26	11002601	SPRING	64	HS0516B	HEX. SOC. HD. BOLT			
27	11002702	GUIDE SAFETY LEVER	65	LN0500N	LOCK NUT			
31	13203101	SAFETY LEVER	66	11106601	COVER			
32	12103202	STEPPED PIN	67	12106401	AIR PLUG			
33	OR0319R	O RING**	68	OR4030R	O RING**			
34	11003401	TRIGGER VALVE HEAD	70	13907001	COLLAR			
35	11003504	TRIGGER VALVE STEM	71	US0506B	UM. HD. BOLT			
36	OR2515H	O RING**	72	FW0512W	FLAT WASHER			
37	OR1119R	O RING**	73	12103301	SEAL			
38	11003803	TRIGGER VALVE GUIDE	74	13907403	EXHAUST COVER			

NO : P13310