


# MODEL: TYI-1850



P13910 07/16/04

## PARTS LIST (TYI-1850)

\*WHEN ORDERING SPARE PARTS, PLEASE STATE ITEM No, PART No. AND DESCRIPTION.

ITEM	PART NO	DESCRIPTION	ITEM	PART NO	DESCRIPTION	ITEM	PART NO	DESCRIPTION
1	HS0530BW	HEX. SOC. HD. BOLT+SW	40A	15104501A	TRIGGER ASSEMBLY			
3	13900305	CAP	41	HS0507B	HEX. SOC. HD. BOLT			
4	12100401	SEAL**	42	HS0520BW	HEX. SOC. HD. BOLT+SW			
5	12100501	SPRING**	44	13104402	DRIVER GUIDE COVER			
6	OR1425R	O RING**	45	12104501	SET PLATE			
7	11100701	CAP SEAL**	46	HS0412B	HEX. SOC. HD. BOLT			
8A	13900801A	HEAD VALVE ASM.	47	13104702	NOSE			
11	OR3224R	O RING**	48	13104802	MAGAZINE COVER			
13-1	OR2435R	O RING**	49	SS0412S	SET SCREW			
13-2	13901304	PISTON RING	50	13905002	MAGAZINE			
14A-1	13901401A	DRIVER ASSEMBLY**	51	HS0406B	HEX. SOC. HD. BOLT			
14A-2	13901402A	DRIVER ASSEMBLY**	52	13905202	END CORE			
18	OR4630R	O RING**	53	13105301	PUSHER			
19-1	13901902	CYLINDER	54	12105401	SPRING**			
19-2	13901902G	CYLINDER	55	12105501	NAIL GUIDE LINER			
19-3	13901903	COLLAR	58	HS0408BW	HEX. SOC. HD. BOLT+SW			
20	13902001	BUMPER**	60	11106001	SPRING**			
21	OR3520R	O RING**	61	13906103	BRACKET			
23	13902301	BODY	64	HS0516B	HEX. SOC. HD. BOLT			
24	OR1919H	O RING**	65	LN0500N	LOCK NUT			
25	10902501	JOINT GUIDE	66	11106601	COVER			
26	11002601	SPRING	67	12106401	AIR PLUG			
27	11002702	GUIDE SAFETY LEVER	68	OR4030R	O RING**			
31	13203101	SAFETY LEVER	70	13907001	COLLAR			
32	12103202	STEPPED PIN	71	US0506B	UM. HD. BOLT			
33	OR0319R	O RING**	72	FW0512W	FLAT WASHER			
34	11003401	TRIGGER VALVE HEAD	73	12103301	SEAL			
35	11003503	TRIGGER VALVE STEM	74	13907403	EXHAUST COVER			
36	OR2515H	O RING**	77	ER0200H	E RING			
37	OR1119R	O RING**	81	13908101	STOPPER			
38	11003803	TRIGGER VALVE GUIDE	82	13908201	SET PLATE			
39	11006901	SPRING	84	13908401	STEPPED PIN			

NO : P13910