



MODEL: TYI-9225



PARTS LIST (TY-9225)

*When ordering spare parts, please state item no, part no. and description.

ITEM	PART NO	DESCRIPTION	ITEM	PART NO	DESCRIPTION	ITEM	PART NO	DESCRIPTION
1	HS0520B	HEX.SOC.HD.BOLT	36	OR2515H	O RING	66	11106601	COVER
2	SW0500W	SPRING WASHER	37	OR1119R	O RING	67	12106401	AIR PLUG
3	11100302	CAP	38	11003803	TRIGGER VALVE GUIDE	68	OR4030R	O RING
4	12100401	SEAL	39	11006901	SPRING	69	11306902	BRACKET
5	12100501	SPRING	40A	15104501A	TRIGGER ASSEMBLY	71	US0506B	UM.HD.BOLT
6	OR1425R	O RING	41	HS0406B	HEX.SOC.HD.BOLT	72	FW0512W	FLAT.WASHER
7	11100701	CAP SEAL	42	11604201	NOSE COVER	73	12103301	SEAL
8A	12100801A	PISTON HEAD VALVE ASM	43	HS0412B	HEX.SOC.HD.BOLT	74	13907403	EXHAUST COVER
8	12100801	PISTON HEAD VALVE	44	HS0520B	HEX.SOC.HD.BOLT	77	ER0200H	E RING
9	OR2535R	O RING	45	SW0500W	SPRING WASHER			
10	12101001	STOPPER	46	12404601	NOSE			
11	OR3224R	O RING	47	11304701	SET PLATE			
13A	11001301A	OIL-LESS PISTON RING ASM	48	12104501	SET PLATE			
14A	11801401A	DRIVER ASSEMBLY	49A	11804901A	STAPLE GUIDE UNIT			
18	OR4630R	O RING	50	11805004	MAGAZINE			
19	11101902G	CYLINDER	51	11805101	PUSHER			
19-1	11101903	COLLAR	52	12405202	SLIDE BLOCK			
20	11002001	BUMPER	53	11305301	SPRING			
21	OR3018R	O RING	54	11305401	ROD			
23	11102307	BODY	56	11305601	SET BLOCK			
24	OR1919H	O RING	57	HS0408B	HEX.SOC.HD.BOLT			
25	11602501	JOINT GUIDE	58	12506801	SET PLATE			
26	11002601	SPRING	59	13908101	STOPPER			
27	11002702	GUIDE SAFETY LEVER	60	11106001	SPRING			
31	11303101	SAFETY LEVER	61	11205801	END CORE			
32	12103202	STEPPED PIN	62	13908401	STEPPED PIN			
33	OR0319R	O RING	63	HS0410B	HEX.SOC.HD.BOLT			
34	11003401	TRIGGER VALVE HEAD	64	HS0516B	HEX.SOC.HD.BOLT			
35	11003503	TRIGGER VALVE STEM	65	LN0500N	LOCK NUT			